

## The Cotton Koozie Kit



Wrap bare piping, use common insulation, secure with wire.



Insulation wrap complete, cut Part No. 20750 Cotton Koozie film.



Wrap insulation with film.



Temporarily secure film with common tape.



Use Cotton Koozie heat gun to shrink film over insulation.



6 hours later, almost finished. UV inhibitors give Koozie film long outdoor life.



**SAMUEL JACKSON, INCORPORATED**

Lubbock, TX USA / Tel: 806-795-5218 / Fax: 806-795-8240 / [www.samjackson.com](http://www.samjackson.com)